

FIGURE 1



FIGURE 2



FIGURE 3



FIGURE 4


48
OBTAIN CONVENTIONAL SLINGSHOT
100
OBTAIN COMPRESSIBLE BALL
102
REPLACE CONVENTIONAL POUCH WITH LAUNCHER POUCH
104
PLACE COMPRESSIBLE BALL INTO LAUNCHER POUCH
106
ORIENT BALL APERTURES TO GENERATE DESIRED SPIN
108
PULL BACK ON GRASPING TAB TO DESIRED TENSION
110
50
AIM BASEBALL TRAINING DEVICE AT BATTER'S STRIKE ZONE
112
RELEASE GRASPING TAB
114

FIGURE 5